

UFO 22

V 1.4

© 2012 OneSails

Tuning guide valid for Set of sails from 2011 or later

Shrouds setting

Tension Gauge Loos&Co PT1-M

Base setting

TWS (kn)	UPPERS	LOWERS	HEADSTAY
0 / 6	- 2	- 4	Just for reference
7 / 10	26	17	16
11 / 14	+ 3	+ 2	-
15 / 19	+ 6	+ 4	-
20 +	+ 6	+ 3	-

Turns variations from the base setting. Turns to be added.

Boat handling

TWS (kn)	Backstay	Wang	Mainsheet	Jib lead	Jib sheet
0 / 6	off	off	upper TT just flying	max fwd for round base	upper TT just flying
7 / 10	10/40 %	off	upper TT just flying	3 cm back from max fwd	upper TT just flying
11 / 14	50/90 %	5 / 30 %	max for right heel	5 cm back from max fwd	upper TT flying
15 / 19	100%	40 / 100 %	max for right heel	7 cm back from max fwd	max for right heel
20 +	100%	100%	max for right heel	7 cm back from max fwd	max for right heel

