



Dolphin 8I tuning guide



SHROUD TENSION

(measured with runner tension = 6)

Base setting tension

TWS Kn.	Uppers	Lowers
0/4	-1 turn	-0,5 turn
4/8	18	15
8/12	+2 turn	+1 turn
12/16	+4 turn	+3 turn
16/20	+5 turn	+4 turn
over 20	+ 6 turn	+5 turn

Tension gauge mod Loose PT-2

