

UFO 22

V 1.5

© 2021 OneSails

Tuning guide valid for Set of sails from 2011 or later

Shrouds setting

Tension Gauge Loos&Co PT1-M

Base setting

| TWS (kn) | UPPERS | LOWERS | HEADSTAY |
|----------|--------|--------|--------------------|
| 0 / 6 | - 2 | - 4 | Just for reference |
| 7 / 10 | 26 | 17 | 16 |
| 7 / 10 | 110 Kg | 50 Kg | 45 Kg |
| 11 / 14 | + 3 | + 2 | - |
| 15 / 19 | + 6 | + 4 | - |
| 20 + | + 6 | + 3 | - |

Turns variations from the base setting. Turns to be added.

Boat handling

| TWS (kn) | Backstay | Wang | Mainsheet | Jib lead | Jib sheet |
|----------|----------|------------|----------------------|------------------------|----------------------|
| 0 / 6 | off | off | upper TT just flying | max fwd for round base | upper TT just flying |
| 7 / 10 | 10/40 % | off | upper TT just flying | 3 cm back from max fwd | upper TT just flying |
| 11 / 14 | 50/90 % | 5 / 30 % | max for right heel | 5 cm back from max fwd | upper TT flying |
| 15 / 19 | 100% | 40 / 100 % | max for right heel | 7 cm back from max fwd | max for right heel |
| 20 + | 100% | 100% | max for right heel | 7 cm back from max fwd | max for right heel |

